

Chapter Five

LANDOWNER SURFACE WATER IMPORTED INTO THE GSA

District Landowners may participate in water exchanges or transfers outside of the GSA boundary that result in surface water being available for direct use by the landowner. Use of that water by the landowner within the GSA requires the use of Irrigation District infrastructure to divert this surface water to their land.

This surface water that is brought into the GSA by the landowner will be tracked and accounted by the GSA and applied to the landowner's water budget according to the following procedures:

1. Surface water brought into the GSA and credited to the landowner will be subject to a loss/reduction factor as determined by the Irrigation District Board of Directors.
2. Surface water brought into the GSA will be delivered to the landowner based upon canal capacity. No surface water delivery brought into the GSA will interrupt or interfere with scheduled allocations of the District surface water supplies.
3. Imported surface water may be used for groundwater recharge subject to the guidelines of the GSP.